

Installation Manual

Date: 05/2018

AQUA-TILT-13


BLACK		WHITE				
Variant	Item No.	Variant	Item No.	Beam Angle	ССТ	
21302		21318	AQUA-13-RND-WHT	60°	2700K	13W Round LED Downlight
21306	AQUA-13-RND-BLK	21322		60°	3000K	
21306 21310	AQUA-13-KND-BLK	21326		60°	4000K	
21314		21330		60°	5000K	

Thank you for purchasing your new LED AQUA, Please take the time to read and understand the instruction sheet below. Failure to do so may void warranty.

Specifications

Voltage:	240V	Lumen (±5%):	Extra Warm White 2700K - 1130lm	Dimmable:	Yes*			
			Warm White 3000K - 1130lm					
			Neutral White 4000K - 1300lm					
			White 5000K - 1220lm					
Power:	13W	Beam Angle:	60°	Operating Temp:	-20°C~45°C			
IP Rating:	65	CCT:	2700K - 3000K - 4000K - 5000K	Power Factor:	≥0.9			
CRI:	≥80	Lifespan:	50,000hrs	Cutout:	Ø90-95mm			
* Tested on the Domus dimmer series. May work on others but not tested.								

Minimum clearance distances to flammable building elements.




Note:


- The LED driver is NOT suitable for covering with insulation material.
- Warning-Risk of overheating or fire if the clearance distances are compromised.
- If the external flexible cable is damaged, it needs to be replaced by the manufacturer or his service agent.
- The light source of this luminaire is not replaceable; at the end of life the whole luminaire should be replaced.




1. Open a hole according to the cutout size of led downlight.



2. Use screw-driver to open the driver terminal cover, feed the main AC wire L.N. in terminal block respectively, then fix the cover back.



3. Connect the downlight with driver, hold back the spring clip then push the downlight into the hole.



4. Make sure the downlight fixed tightly in ceiling, turn on the power.



IC-4