# DOMUS®

29-31 Richland St. Kingsgrove. Sydney NSW 2208 Australia
Phone: 02 9554 9600    |    Fax: 02 9554 9433
enquiries@domuslighting.com.au    |    www.domuslighting.com.au

## Installation Manual

## EXPO-10-REC

Date: 03/2019

| Variants | | Item No. | Colour Temp | |
|----------|----------|----------|----------|---|
| *Blk* | *Wht* | | | |
| **20710** | **20711** | **EXPO-10-REC** | TRIO | |

*Description: LED Recessed Downlight*

Thank you for purchasing your new EXPO-10-REC Wall Light, Please take the time to read and understand the instruction sheet below. Failure to do so may void warranty.

## Specifications

| Voltage: | 240V | Lumen (±5%): | Warm White 3000K - 710lm<br>Neutral White 4000K - 780lm<br>White 5700K - 850lm | Dimmable: | Yes |
|----------|------|--------------|---------------------------------|-----------|-----|
| Power: | 10W | Beam Angle: | 80° | Operating Temp: | -20°~45°C |
| IP Rating: | IP44 | CCT: | 3000K - 4000K - 5700K (Switchable) | | |
| CRI: | ≥80 | Lifespan: | 50,000hrs | | |

For the product with Slide Switch of Color Selection, please select the light color (DL/CW/WW) before installation.

WW
NW
W
Slide switch for
color selection



**Step 1**
Open a hole according to the cutout size of LED downlight



**Step 2**
Use screw-driver to open the driver terminal cover, feed the main AC wire L. N. in terminal block respectively, then fix the cover back.



**Step 3**
Connect the downlight with driver, hold back the spring clip then push the downlight into the hole.



**Step 4**
Connect the downlight with driver, hold back the spring clip then push the downlight into the hole



**Note:**
-The lamp must be installed by professional electrician
-Ensure the power supply is switched off before fitting this product
-Do not touch the lamp when in use
-Keep away from hot steam and corrosive gas