

29-31 Richland St. Kingsgrove. Sydney NSW 2208 Australia

Phone: 02 9554 9600 | Fax: 02 9554 9433

enquiries@domuslighting.com.au | www.domuslighting.com.au

Installation Manual

EXPO-35-REC

Variants Colour Temp Item No. Blk Wht 20714 20715 EXPO-35-REC TRIO

Description: LED Recessed Downlight

Thank you for purchasing your new EXPO-35-REC Wall Light, Please take the time to read and understand the instruction sheet below. Failure to do so may void warranty.

Specifications

Voltage:	240V	Lumen (±5%):	Warm White 3000K - 3650lm Neutral White 4000K - 37500lm White 5700K - 3850lm	Dimmable:	Yes
Power:	35W	Beam Angle:	80°	Operating Temp:	-20°~45°C
IP Rating:	IP44	CCT:	3000K - 4000K - 5700K (Switchable)		
CRI:	≥80	Lifespan:	50,000hrs		


For the product with Slide Switch of Color Selection, please select the light color (DL/CW/WW) before installation.




Step 1 Open a hole according to the cutout size of LED downlight




Step 2 Use screw-driver to open the driver terminal cover, feed the main AC wire L. N. in terminal block respectively, then fix the cover back.



Step 3 Connect the downlight with driver, hold back the spring clip then push the downlight into the hole.



Step 4 Connect the downlight with driver, hold back the spring clip then push the downlight into the hole



Note: -The lamp must be installed by professional electrician

-Ensure the power supply is switched off before fitting this product

-Do not touch the lamp when in use

-Keep away from hot steam and corrosive gas