

29-31 Richland St. Kingsgrove. Sydney NSW 2208 Australia

Phone: 02 9554 9600 | Fax: 02 9554 9433

enquiries@domuslighting.com | www.domuslighting.com

Installation Manual

JET-4SQ

Order Code	Product Code	Description	
20662	JET-4SQ-W-WW	40W LED 4 Bar White Spotlight, Warm White 3000K	
20663	JET-4SQ-W-W	40W LED 4 Bar White Spotlight, White 5000K	
20664	JET-4SQ-S-WW	40W LED 4 Bar Silver Spotlight, Warm White 3000K	
20665	JET-4SQ-S-W	40W LED 4 Bar Silver Spotlight, White 5000K	


Thank you for purchasing your new LED JET-4SQ spotlight, Please take the time to read and understand the instruction sheet below. Failure to do so may void warranty.

Specifications


Voltage:	240V AC	Lumen (±5%):	Warm White 3000K - 3480lm	Dimmable:	Yes*		
			White 5000K - 3680lm				
Power:	40W	Beam Angle:	45°	Operating Temp:	-20°C-45°C		
IP Rating:	20	CCT:	3000K - 5000K	Power Factor:	≥0.9		
CRI:	≥80	Lifespan:	40,000hrs				

Surface Mounted:


1. Knock-in the plastic anchors into the ceiling hole




2.Fix bracket with screws



3. Connect power supply



4. Hang the spotlight of bracket and tighten screws



Note: -The lamp must be installed by professional electrician

-Ensure the power supply is switched off before fitting this product

-Do not touch the lamp when in use

-Keep away from hot steam and corrosive gas




Phone: 02 9554 9600 | Fax: 02 9554 9433

enquiries@domuslighting.com | www.domuslighting.com


Installation Manual

Semi-Recessed:


1.Cutout: 269x269mm



3. Hold the spring clips upwards and insert spotlight into position



2.Connect power supply



4.Finish

